

### WHEEL LOADER



NET HORSEPOWER 299 HP @ 2000 rpm 223 kW @ 2000 rpm **OPERATING WEIGHT 57,232 lb – 61,311 lb** 25960 kg – 27810 kg

**BUCKET CAPACITY 6.0 – 7.2 yd³**4.6 – 5.5 m³

## **WALK-AROUND**



**NET HORSEPOWER 299 HP @ 2000 rpm** 223 kW @ 2000 rpm **OPERATING WEIGHT 57,232 lb – 61,311 lb** 25960 kg – 27810 kg

**BUCKET CAPACITY 6.0 – 7.2 yd³** 4.6 – 5.5 m³



### PERFORMANCE, DURABILITY AND FUEL ECONOMY

Large capacity torque converter with lock-up:

Quick acceleration

Lock-up in 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> gear

Komatsu SmartLoader Logic helps reduce fuel consumption with no decrease in production.



The **Yard Loader arrangement** features a 7.2 yd³ genuine Komatsu high performance bucket, low profile 775/65/ R29 tires, an improved brake cooling system and a heavier Yard Loader counter weight, and is designed to three pass typical on-highway trucks.

A powerful Komatsu SAA6D125E-7 engine provides a net output of 223 kW 299 HP with up to 20% improved fuel consumption.\* This engine is EPA Tier 4 Final emissions certified.

Variable Geometry Turbocharger (VGT) uses a hydraulic actuator to provide optimum air flow under all speed and load conditions.

Komatsu Diesel Particulate Filter (KDPF) and Selective Catalytic Reduction (SCR) systems reduce particulate matter and NOx while providing automatic regeneration that does not interfere with daily operation.

#### Fluid neutral or better

Fuel & DEF total consumption is less than fuel consumed by the prior model.

### Coolina

- · Hydraulically driven, variable speed
- · Auto-reversing fan is standard
- · Wider core coolers resist clogging
- · Swing out fan for easy cleaning

Remote boom and bucket positioners can set kick-outs from inside the cab.

Variable displacement piston pumps with CLSS provides quick response and smooth operation to maximize productivity.

### Rearview monitoring system (standard)

**Advanced diagnostic system** continuously monitors machine operation and vital systems to identify machine issues and assist with troubleshooting.

**Transmission Mode Select System (3 modes)** allows shifting mode to be matched more efficiently to varying work applications.

#### **Enhanced working environment:**

- · High capacity air suspension seat, heated
- · Seat mounted EPC controls with F-N-R switch
- (2) 12V power outlets

New style of front fender is plastic for durability.

**Rear full fenders (standard)** are made of durable plastic and swing open for easy access to maintenance points.

### Large LCD color monitor panel:

- 7" high resolution, multi-color screen is easy to read
- Provides "Ecology Guidance" for fuel efficient operation
- Onboard diagnostics do not require use of a laptop computer
- Multiple choice, pulldown menus are filled with useful functions

Komatsu Auto Idle Shutdown helps reduce idle time and operating costs.

External mounting of engine air filter (above rear LH fender) provides easy access for maintenance.

The **KOMTRAX**® telematics system is standard on Komatsu equipment with no subscription fees throughout the life of the machine. Using wireless technology, **KOMTRAX**® transmits valuable information such as location, utilization, and maintenance records to a PC or smartphone app. Custom machine reports are provided for identifying machine efficiency and operating trends. **KOMTRAX**® also provides advanced machine troubleshooting capabilities by continuously monitoring machine health.

Battery disconnect switch allows a technician to disconnect and lockout the power supply before servicing the machine.


**Operator Identification System** can track machine operation for up to 100 operators.

### PERFORMANCE FEATURES

### KOMATSU NEW ENGINE TECHNOLOGIES

#### **New Tier 4 Final Engine**


The Komatsu SAA6D125E-7 engine is EPA Tier 4 Final emissions certified and provides exceptional performance while reducing fuel consumption. Based on Komatsu proprietary technologies developed over many years, this new diesel engine reduces nitrogen oxides (NOx) by more than 80% when compared to Tier 4 interim levels.



### **Technologies Applied to New Engine**

### Heavy-duty aftertreatment system


This new system combines a Komatsu Diesel Particulate Filter (KDPF) and Selective Catalytic Reduction (SCR). The SCR NOx reduction system injects the correct amount of Diesel Exhaust Fluid (DEF) at the proper rate, thereby decomposing NOx into non-toxic water vapor (H<sub>2</sub>O) and nitrogen gas (N<sub>2</sub>).



### Heavy-duty cooled Exhaust Gas Recirculation (EGR) system

The system recirculates a portion of exhaust gas into the air intake and lowers

combustion temperatures, thereby reducing NOx emissions. EGR gas flow has been decreased for Tier 4 Final with the addition of SCR technology. The system




### Advanced Electronic Control System The electronic control system performs high

The electronic control system performs high-speed processing of all signals from sensors installed in the vehicle providing total control of equipment. Engine condition information is displayed on the monitor inside the cab, providing necessary information to the operator. Additionally, managing the information via KOMTRAX helps customers keep up with required maintenance.

### Variable Geometry Turbocharger (VGT) system


The VGT system features proven Komatsu design hydraulic technology for variable control of air-flow and supplies optimal air according to load conditions. The upgraded version provides better exhaust temperature management.



### Heavy-duty High-Pressure Common Rail (HPCR) fuel injection system

The system is designed to achieve an optimal injection of

high-pressure fuel digitally, thereby bringing near complete combustion to reduce PM emissions.



This wheel loader offers three selectable operating modes — E, P, and E-light.

- E Mode: This mode provides maximum fuel efficiency for general loading.
- P Mode: This mode provides maximum power output for hard digging operation or hill climbing.

**Engine Power Select System** 



- 1 Dual mode engine power selection switch
- 2 Transmission shift mode selector switch
- 3 Torque converter lock-up switch
- 4 Automatic digging ON/OFF switch

### Komatsu SmartLoader Logic

The WA480-8 provides Komatsu SmartLoader Logic, an engine control system. This technology creates enough torque for each work phase. For example, engine torque needs are higher for digging in V-shape loading, but less when driving with an empty bucket. This system optimizes the engine torque for all applications to minimize fuel consumption. Komatsu SmartLoader Logic functions automatically and doesn't interfere with operation, saving fuel without decreasing production.

### **Large-capacity Torque Converter**

The Komatsu designed power train has a large capacity torque converter for optimum efficiency. The WA480-8 has greater productivity in V-shape loading applications because the increased tractive effort does not require full throttle. The improved hill climbing ability allows the WA480-8 to up-shift gears faster because of improved acceleration. The WA480-8 can achieve higher gear ranges and maintain higher travel speed when working in load-and-carry applications. In most applications, production is increased and fuel consumption is reduced, resulting in improved fuel efficiency.

### **Enhanced Lock-up**

The Komatsu designed torque converter with lock-up is standard on the WA480-8. The lock-up function activates in 2nd, 3rd and 4th gears. The lock-up torque converter is effective for both load and carry application and V-shape loading which uses lower gears. Komatsu SmartLoader Logic reduces the clutch engagement shock of lock-up by controlling engine torque. The lock-up torque converter combined with Komatsu SmartLoader Logic results in low fuel consumption and high travel speeds in load and carry and even some V-cycle loading applications.

**New E-light Mode** is activated in the monitor panel for the lowest possible fuel consumption. When activated, the engine matches power to the working conditions, for higher fuel efficiency. The work equipment and steering pumps are electronically controlled to prevent waste and deliver the exact amount required.

### **Automatic Transmission with Mode Select System**

This operator controlled system allows the operator to select manual shifting or two levels of automatic shifting (low, and high). Auto L mode is for fuel saving operation with the gear shift timing set at lower speeds than Auto H mode. Therefore Auto L mode keeps the engine in a relatively low rpm range for fuel conservation while yielding required tractive force by operator depressing the accelerator pedal.

#### **Variable Displacement Piston Pump & CLSS**

The variable displacement piston pump combined with the Closed-center Load Sensing System (CLSS) delivers hydraulic flow just as the job requires preventing wasted hydraulic flow. Minimized loss contributes to better fuel economy.

### Komatsu Auto Idle Shutdown

In order to reduce idle time, Komatsu offers Komatsu Auto Idle Shutdown. This function will shut the engine off and apply the parking brake and hydraulic lock after a preset idle time limit. This time limit can be set by the operator or service technician and may range from 3 minutes to 60 minutes.



### **OPERATOR ENVIRONMENT**



### New Operator Seat with Electronic Pilot Control (EPC) Levers

A new air suspension seat provides enhanced support on

rough roads and dampens machine vibrations, providing a more comfortable ride for the operator. An EPC lever console is integrated in the seat and moves with the seat. The angle of the armrest is fully adjustable for optimum operator comfort. A secondary F-N-R switch is incorporated in work equipment lever configurations. A heated seat is standard.



### Tiltable / Telescopic Steering Wheel

The operator can both tilt and telescope the steering wheel to allow maximum comfort and control. The two spoke steering wheel allows maximum visibility of the monitor panel and the forward work environment.



### **Low Noise Design**

Operator's ear noise level : 72 dB(A)\*

Dynamic noise level (outside): 112 dB(A)\*\*

The large cab is mounted with Komatsu's unique ROPS/FOPS viscous mounts. The low-noise engine, hydraulically driven fan, and hydraulic pumps are mounted with rubber cushions, and the cab sealing is improved to provide a quiet, low-vibration, dust-proof, and comfortable operating environment.

- \* ISO 6396: 2008
- \*\* ISO 6395: 2008

### Mono-lever with Integrated 3rd Spool Control (Optional)

The mono-lever allows the operator to control the optional 3rd spool with your thumb which greatly increases ease of operation. The 3rd spool valve can be operated in either continuous or proportional flow modes. The mono-lever also includes a F-N-R switch.



### **Rear View Monitoring System (standard)**

The operator can view the rear of the machine with a full color monitor that is located on the right side of the cab. This monitor can be always on or only on when the loader goes into reverse. Visual guidelines can also be added for more convenience.





### **Engine Shutdown Secondary Switch**

The engine stop switch is incorporated to allow shutdown of the machine when accessing the key switch is not possible.






### Auxiliary Input (MP3 Jack) 12 V Outlets

An Aux input for digital devices is standard as well as two 12 volt outlets. These are all located on the front of the right hand console.



### **WORKING ENVIRONMENT**



### **Easy Entry and Egress**

The WA480-8 has an inclined ladder with wide steps and hand holds to ease entry and exit from the cab.

### **Remote Bucket & Boom Positioner**

The operator can set the bucket angle and remote boom positioner from the cab. Both upper and lower boom positions are adjustable in the cab with the push of a button. The bucket positioner can memorize three horizontal settings, allowing the operator to easily change attachments without having to reset the bucket position. In each horizontal setting, the operator can adjust the setting with the switch in the cab. This can help save the operator time when changing attachments.



Remote positioner switch Boom / Bucket

### **Automatic Kick-down**

The WA480-8 has the ability to automatically shift down to F1. This can be activated through the monitor.





### **Electronically Controlled Suspension System**

The Electronically Controlled Suspension System (ECSS) or ride control system uses an accumulator which minimizes boom arm shock, giving the operator a much smoother ride. This reduces operator fatigue and reduces material spillage during load and carry operations. ECSS is speed sensitive, meaning that the boom won't move during stationary digging. ECSS is standard on the WA480-8.

### Advanced Joystick Steering System (AJSS) (option)

Allows steering and directional travel to be controlled by wrist and finger control to minimize operator fatigue in high duty cycle applications. AJSS allows for full speed

travel speed while maintaining precise steering and control.



### **New Bucket Design**

The newly designed bucket improves overall machine productivity. Generous curves on the side wall and wrap improve pile penetration and make it easy to fill. They also improve material retention in carry operations.



### **High Resolution 7-inch Color LCD Monitor**

The machine monitor display various machine information and allows for various settings of the machine. The LCD monitor is a 7-inch color TFT-LCD and displays maintenance information, operation record, Ecology Guidance record, and other machine data. The switch panel is used to select various screens and the air conditioner control screen. By using the switch panel, you can display various user menus on the LCD screen and adjust the machine settings.

#### Machine monitor

- 1 LCD unit
- 2 LED unit
- 3 Engine tachometer
- 4 Speedometer
- 5 Ecology gauge
- 6 Air conditioner display
- Shift indicator

### Switch panel

1 Air conditioner switches / Numeral key pad



8 Engine coolant temperature gauge

Torque converter oil temperature gauge

9 Hydraulic oil temperature gauge

#### Visual user menu

Pressing the menu switch on the switch panel displays the user menu screen. The menus are grouped for each function, and use easy-to-understand icons which enable the machine to be operated intuitively.

11 Fuel gauge

13 Pilot lamps

14 DEF level gauge

12 Message pilot lamp



- 1 Energy saving guidance
- 2 Load meter setting (optional)
- 3 Machine settings
- 4 Aftertreatment devices regeneration
- 6 SCR information
- 6 Maintenance
- Monitor setting
- 8 Mail check



### Operator identification function

An operator identification (ID) can be set for each operator, and used to manage operation information of individual machines as KOMTRAX data. Data sent from KOMTRAX can be used to analyze

operation status by operator as well as by machine.



### Machine monitor with troubleshooting function to minimize downtime

Various meters, gauges and warning functions are centrally arranged on the machine monitor. The monitor simplifies start-up inspection and promptly warns the operator with a lamp and buzzer if any abnormalities should occur. In addition, countermeasures are indicated in 4 levels to ensure safety and help prevent the machine

from having major problems.

Replacement times for oil and filters are also indicated.



### **MAINTENANCE FEATURES**



### **Side-opening Gull-wing Engine Doors**

The large gull-wing type engine doors require less effort to open and close thanks to gas assisted struts. The doors provide wide areas of access for ease of daily maintenance.

Large steps on each side of the frame enhance accessibility.



### **Auto Reversing Fan**

The engine cooling fan is driven hydraulically. It can be set to reverse automatically during operation. Fan reverse mode and timing can be controlled through the monitor.

Ø € ⟨⇒⟩ ಓ ⊠ \			
E light Mode/E Mode Selection	E		
Manual Fan Reverse Mode	Norma I		
Automatic Fan Reverse Mode	Mode A		
2-Stage Low Idle Setting	0FF		
<b>▼</b> ENCL Bucket Level Position Selection	Α		

### **Easy access Wide Core Radiator**

The door swings open for easy cleaning. The coolers feature wide spacing of the cooling fins to reduce clogging.



### **DEF Tank**

The DEF tank is located on the right hand side of the machine behind a ladder for easy access. An external sight gauge aids in preventing overflow and spillage while refilling. A new magnetized holder is provided for added convenience.




The battery disconnect switch is located in the right side of the engine. This can be used to disconnect power when performing service work on the machine. The switch can also be locked out using a personal lock or hasp.





### **Engine Compartment**

The WA480-8 engine compartment is designed for easy serviceability. Placement of maintenance items, such as filters, dipsticks, oil fill locations, and aftertreatment devices is all very intuitive.





Engine oil fill Fuel filter Oil filter
Engine oil dipstick Fuel pre-filter

### **Rear Full Fenders (Standard)**

The WA480-8 has a rear full fender standard. The plastic rear fenders open outward, keeping the force to open the engine doors low, even when there is mud or snow on the fenders.

The fenders swing far out of the way to give the technician easy access to the engine compartment. Mudflaps are also included on the rear fenders.



#### Air Conditioner Filter

The inside and outside air conditioner filters can be replaced easily without using a tool. The outside filter is located behind

a lockable door for security.





Inside air filter

Outside air filter

### **LED Taillights**

LED brake lights and LED reverse lights provide long bulb life.



#### Air Cleaner

The air cleaner is located on the left side platform for easy access.



### **Maintenance Information**

### "Maintenance time caution lamp" display

When the remaining time to maintenance becomes less than 30 hours\*, the maintenance time monitor appears. Pressing the menu switch displays the maintenance screen.

\*: The setting can be changed within the range between 10 and 200 hours.



Maintenance	Interval	Remain	
Air Cleaner Cleaning or Change			
Goolant Change	500 h	498 h	
🗝 Fuel Prefilter Change	500 h	499 h	
Engine Oil Change	500 h	10 h	
Engine Oil Filter Change	500 h	499 h	
	<b>✓</b>		

Maintenance screen

### Supports the DEF level and refill timing

The DEF level gauge is displayed continuously on the monitor screen. In addition, when the refill timing is reached, the DEF low level guidance appears as a pop up display to inform the operator in real time.





DEF level gauge

DEF low level guidance

# KOMATSU PARTS & SERVICE SUPPORT



### **KOMATSU CARE**

### **Program Includes:**

\*The WA480-8 comes standard with complimentary factory scheduled maintenance for the first 3 Years or 2,000 Hours, whichever comes first.

### **Planned Maintenance Intervals at:**

500/1000/1500/2000 hour intervals. (250 hr. initial interval for some products) Complimentary Maintenance Interval includes: Replacement of Oils & Fluid Filters with genuine Komatsu Parts, 50-Point inspection, Komatsu Oil & Wear Analysis Sampling (KOWA) / Travel & Mileage (distance set by distributor; additional charges may apply)

### **Benefits of Using Komatsu CARE**

- Assurance of Proper Maintenance with OEM Parts & Service
- Increased Uptime & Efficiency
- Factory Certified Technicians Performing Work
- Cost of Ownership Savings
- Transferable Upon Resale

### Complimentary KDPF exchange

The WA480-8 comes standard with one complimentary Komatsu Diesel Particulate Filter (KDPF) exchange unit for the first five years or 4,500 hours, whichever occurs first. End user must have an authorized Komatsu distributor perform the removal and installation of the KDPF.

### Complimentary SCR system maintenance

The WA480-8 also includes one factory-suggested service of the selective catalytic reduction (SCR) and diesel exhaust fluid (DEF) system during the first five years or 4,500 hours, whichever occurs first. End user must have an authorized Komatsu distributor perform the SCR maintenance.

Interval PM    1250   500   1000   1500   2000	Interval PM	:050	500	1000	4500	0000
engine, transmission, hydraulics, front & rear axle CLEAN AC FRESH AND RECIRC AIR FILTERS REPLACE HYDRAULIC OIL FILTER ELEMENT REPLACE TRANSMISSION OIL FILTER CHECK AND CLEAN AIR CLEANER CHECK AND CLEAN FUEL BREATHER ELEMENT LUBRICATE REAR AXLE PIVOT PIN LUBRICATE WORK EQUIPMENT CHECK PARKING BRAKE CHECK WHEEL HUB BOLTS AND RETIGHTEN AS NECESSARY DRAIN SEDIMENT FROM FUEL TANK COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS CHANGE ENGINE OIL REPLACE AC FRESH & RECIRC AIR FILTERS REPLACE FUEL MAIN FILTER REPLACE FUEL MAIN FILTER REPLACE TANSMISSION OIL STRAINER LUBRICATE CONTENT OF THE SUPPORT CHANGE FRONT AND REAR AXLE OIL REPLACE HYDRAULIC TANK BREATHER LUBRICATE CENTER HINGE PIN LUBRICATE DRIVE SHAFT CENTER SUPPORT CHANGE FRONT AND REAR AXLE OIL REPLACE HYDRAULIC TANK BREATHER ELEMENT CLEAN HYDRAULIC OIL STRAINER CHANGE HYDRAULIC OIL STRAINER CHANGE HYDRAULIC OIL REPLACE DEF PUMP FILTER		1250	ວບບ	1000	1500	2000
CLEAN AC FRESH AND RECIRC AIR FILTERS  REPLACE HYDRAULIC OIL FILTER ELEMENT  REPLACE TRANSMISSION OIL FILTER  CHECK AND CLEAN AIR CLEANER  CHECK AND CLEAN FUEL BREATHER ELEMENT  LUBRICATE REAR AXLE PIVOT PIN  LUBRICATE WORK EQUIPMENT  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN  AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM;  LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE  COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL MAIN FILTER  REPLACE FUEL MAIN FILTER  REPLACE TANSMISSION BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  CHANGE TRANSMISSION BREATHER ELEMENT  CHANGE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  CHANGE TRANSMISSION OIL  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC OIL STRAINER  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE REPLACE RESEM AXLE OIL  REPLACE DEF PUMP FILTER	` ' '	1	1	1	1	✓
REPLACE HYDRAULIC OIL FILTER ELEMENT  REPLACE TRANSMISSION OIL FILTER  CHECK AND CLEAN AIR CLEANER  CHECK AND CLEAN FUEL BREATHER ELEMENT  LUBRICATE REAR AXLE PIVOT PIN  LUBRICATE WORK EQUIPMENT  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN  AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM;  LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE  COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL FILTER  REPLACE ENGINE OIL FILTER  REPLACE FUEL MAIN FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION OIL STRAINER  LUBRICATE CHORE SHAFT CENTER SUPPORT  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER						
REPLACE TRANSMISSION OIL FILTER  CHECK AND CLEAN AIR CLEANER  CHECK AND CLEAN FUEL BREATHER ELEMENT  CHECK AND CLEAN FUEL BREATHER ELEMENT  CHECK AND CLEAN FUEL BREATHER ELEMENT  LUBRICATE REAR AXLE PIVOT PIN  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN  AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM;  LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE  COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL FILTER  REPLACE ENGINE OIL FILTER  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL MAIN FILTER  REPLACE FUEL MAIN FILTER  REPLACE TRANSMISSION OIL STRAINER  CLEAN TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE DEF PUMP FILTER		-				
CHECK AND CLEAN AIR CLEANER  CHECK AND CLEAN FUEL BREATHER ELEMENT  LUBRICATE REAR AXLE PIVOT PIN  LUBRICATE WORK EQUIPMENT  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN  AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM;  LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE  COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER						
CHECK AND CLEAN FUEL BREATHER ELEMENT  CHECK AND CLEAN FUEL BREATHER ELEMENT  LUBRICATE REAR AXLE PIVOT PIN  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN  AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM;  LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE  COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL PRE-FILTER  REPLACE FUEL MIN FILTER  CLEAN TRANSMISSION BREATHER  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  CHANGE TRANSMISSION OIL  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER					_	
LUBRICATE REAR AXLE PIVOT PIN  LUBRICATE WORK EQUIPMENT  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE  COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL PRE-FILTER  REPLACE FUEL MRIN FILTER  CLEAN TRANSMISSION BREATHER  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  CHANGE TRANSMISSION OIL  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER			-			•
LUBRICATE WORK EQUIPMENT  CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL REPLACE ENGINE OIL FILTER REPLACE AC FRESH & RECIRC AIR FILTERS REPLACE FUEL PRE-FILTER REPLACE FUEL PRE-FILTER REPLACE FUEL MAIN FILTER  REPLACE TRANSMISSION BREATHER CLEAN TRANSMISSION BREATHER LUBRICATE CENTER HINGE PIN LUBRICATE CENTER HINGE PIN LUBRICATE CENTER HINGE PIN CHANGE TRANSMISSION OIL CHANGE TRANSMISMISMISMISMISMISMISMISMISMISMISMISMIS						•
CHECK PARKING BRAKE  CHECK WHEEL HUB BOLTS AND RETIGHTEN AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE FUEL MAIN FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER CLEAN TRANSMISSION BREATHER ELEMENT  LUBRICATE CHIEF SHAFT CENTER SUPPORT  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC OIL STRAINER  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE FRONT AND REAR AXLE OIL  REPLACE DEF PUMP FILTER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER			-	_		
CHECK WHEEL HUB BOLTS AND RETIGHTEN AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE FUEL MAIN FILTER  REPLACE FUEL MAIN FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER CLEAN TRANSMISSION BREATHER ELEMENT  LUBRICATE CENTER HINGE PIN  LUBRICATE CRITER HINGE PIN  LUBRICATE CRITER HINGE PIN  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC OIL STRAINER  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE DEF PUMP FILTER  CHANGE RYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE REPLACE DEF PUMP FILTER  CHANGE REPLACE DEF PUMP FILTER  REPLACE DEF PUMP FILTER  REPLACE DEF PUMP FILTER	LUBRICATE WORK EQUIPMENT	•			-	
AS NECESSARY  DRAIN SEDIMENT FROM FUEL TANK  COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE FUEL PRE-FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC OIL STRAINER  CLEAN HYDRAULIC OIL  REPLACE DEF PUMP FILTER  AV AV  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE DEF PUMP FILTER  AV AV  CHANGE RONT AND REAR AYLE OIL  REPLACE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  CHANGE HYDRAULIC OIL	CHECK PARKING BRAKE	✓	✓	✓	1	✓
COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS CHANGE ENGINE OIL REPLACE ENGINE OIL FILTER REPLACE AC FRESH & RECIRC AIR FILTERS REPLACE FUEL PRE-FILTER REPLACE FUEL MAIN FILTER REPLACE TELL MAIN FILTER REPLACE TELL MAIN FILTER CLEAN TRANSMISSION BREATHER CLEAN TRANSMISSION OIL STRAINER LUBRICATE CENTER HINGE PIN LUBRICATE CENTER HINGE PIN LUBRICATE TRANSMISSION OIL CHANGE HYDRAULIC TANK BREATHER ELEMENT CLEAN HYDRAULIC OIL STRAINER CHANGE HYDRAULIC OIL REPLACE DEF PUMP FILTER		✓	✓	✓	✓	✓
COMPLETE 50 POINT INSPECTION FORM; LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL REPLACE ENGINE OIL FILTER REPLACE AC FRESH & RECIRC AIR FILTERS REPLACE FUEL PRE-FILTER REPLACE FUEL MAIN FILTER REPLACE TRANSMISSION BREATHER CLEAN TRANSMISSION BREATHER ELEMENT REPLACE TRANSMISSION OIL STRAINER LUBRICATE CENTER HINGE PIN LUBRICATE CENTER HINGE PIN LUBRICATE CENTER HINGE PIN CHANGE TRANSMISSION OIL CHANGE HYDRAULIC TANK BREATHER ELEMENT CLEAN HYDRAULIC OIL STRAINER CHANGE HYDRAULIC OIL REPLACE DEF PUMP FILTER	DRAIN SEDIMENT FROM FUEL TANK	1	1	<b>√</b>	1	1
LEAVE PINK COPY WITH CUSTOMER OR IN CAB  RESET MONITOR PANEL MAINTENANCE COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL PRE-FILTER  REPLACE FUEL MAIN FILTER  REPLACE TUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  CHANGE TRANSMISSION OIL  CHANGE TRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER			,	,		
COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL PRE-FILTER  REPLACE FUEL PRE-FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER		✓	<b>V</b>	<b>V</b>	<b>V</b>	<b>V</b>
COUNTER FOR APPROPRIATE ITEMS  CHANGE ENGINE OIL  REPLACE ENGINE OIL FILTER  REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL PRE-FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE DEF PUMP FILTER	RESET MONITOR PANEL MAINTENANCE	1	1	1	1	1
REPLACE ENGINE OIL FILTER REPLACE AC FRESH & RECIRC AIR FILTERS REPLACE FUEL PRE-FILTER REPLACE FUEL MAIN FILTER REPLACE FUEL MAIN FILTER REPLACE DEF TANK BREATHER CLEAN TRANSMISSION BREATHER ELEMENT REPLACE TRANSMISSION OIL STRAINER LUBRICATE CENTER HINGE PIN LUBRICATE DRIVE SHAFT CENTER SUPPORT CHANGE TRANSMISSION OIL CHANGE FRONT AND REAR AXLE OIL REPLACE HYDRAULIC TANK BREATHER ELEMENT CLEAN HYDRAULIC OIL STRAINER CHANGE HYDRAULIC OIL REPLACE DEF PUMP FILTER	COUNTER FOR APPROPRIATE ITEMS	•	•	•	•	•
REPLACE AC FRESH & RECIRC AIR FILTERS  REPLACE FUEL PRE-FILTER  REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE CENTER HINGE PIN  CHANGE TRANSMISSION OIL  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE DEF PUMP FILTER	CHANGE ENGINE OIL		✓	✓		✓
REPLACE FUEL PRE-FILTER REPLACE FUEL MAIN FILTER REPLACE DEF TANK BREATHER CLEAN TRANSMISSION BREATHER ELEMENT REPLACE TRANSMISSION OIL STRAINER LUBRICATE CENTER HINGE PIN LUBRICATE DRIVE SHAFT CENTER SUPPORT CHANGE TRANSMISSION OIL CHANGE FRONT AND REAR AXLE OIL REPLACE HYDRAULIC TANK BREATHER ELEMENT CHANGE HYDRAULIC OIL STRAINER CHANGE HYDRAULIC OIL REPLACE DEF PUMP FILTER REPLACE DEF PUMP FILTER	REPLACE ENGINE OIL FILTER		1	<b>√</b>	1	✓
REPLACE FUEL MAIN FILTER  REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CHANGE HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	REPLACE AC FRESH & RECIRC AIR FILTERS		1	<b>√</b>	1	✓
REPLACE DEF TANK BREATHER  CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	REPLACE FUEL PRE-FILTER		1	<b>√</b>	1	✓
CLEAN TRANSMISSION BREATHER ELEMENT  REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	REPLACE FUEL MAIN FILTER			✓		✓
REPLACE TRANSMISSION OIL STRAINER  LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	REPLACE DEF TANK BREATHER			✓		✓
LUBRICATE CENTER HINGE PIN  LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	CLEAN TRANSMISSION BREATHER ELEMENT			<b>√</b>		✓
LUBRICATE DRIVE SHAFT CENTER SUPPORT  CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	REPLACE TRANSMISSION OIL STRAINER			<b>√</b>		✓
CHANGE TRANSMISSION OIL  CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	LUBRICATE CENTER HINGE PIN			<b>√</b>		✓
CHANGE FRONT AND REAR AXLE OIL  REPLACE HYDRAULIC TANK BREATHER  ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	LUBRICATE DRIVE SHAFT CENTER SUPPORT					✓
REPLACE HYDRAULIC TANK BREATHER ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	CHANGE TRANSMISSION OIL					✓
ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	CHANGE FRONT AND REAR AXLE OIL					✓
ELEMENT  CLEAN HYDRAULIC OIL STRAINER  CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	REPLACE HYDRAULIC TANK BREATHER					1
CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	ELEMENT					<b>v</b>
CHANGE HYDRAULIC OIL  REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER	CLEAN HYDRAULIC OIL STRAINER					✓
REPLACE DEF PUMP FILTER  REPLACE KCCV FILTER						<b>√</b>
REPLACE KCCV FILTER ✓	REPLACE DEF PUMP FILTER					<b>√</b>
	REPLACE KCCV FILTER					✓
		1	1	✓	<b>√</b>	<b>1</b>
KDPF exchange suggested at 4,500 hrs.						
SCR system maintenance suggested at 4,500 hrs.						

### Komatsu CARE® - Extended Coverage

- Extended Coverage can provide peace of mind by protecting customers from unplanned expenses that effect cash flow
- Purchasing extended coverage locks-in the cost of covered parts and labor for the coverage period and helps turn these into fixed costs



### **Komatsu Parts Support**

- 24/7/365 to fulfill your parts needs
- 9 parts Distribution Centers strategically located across the U.S. and Canada
- Distributor network of more than 300 locations across U.S. and Canada to serve you
- Online part ordering through Komatsu eParts
- Remanufactured components with same-as-new warranties at a significant cost reduction



### Komatsu Oil and Wear Analysis (KOWA)

- KOWA detects fuel dilution, coolant leaks, and measures wear metals
- Proactively maintain your equipment
- Maximize availability and performance
- Can identify potential problems before they lead to major repairs
- Reduce life cycle cost by extending component life

<sup>\*</sup> Certain exclusions and limitations apply. Refer to the customer certificate for complete program details and eligibility.

### **KOMTRAX EQUIPMENT MONITORING**



- KOMTRAX is Komatsu's remote equipment monitoring and management system
- KOMTRAX continuously monitors and records machine health and operational data
- Information such as fuel consumption, utilization, and a detailed history lowering owning and operating cost



- Know when your machines are running or idling and make decisions that will improve your fleet utilization
- Detailed movement records ensure you know when and where your equipment is moved
- Up to date records allow you to know when maintenance is due and help you plan for future maintenance needs





- KOMTRAX data can be accessed virtually anywhere through your computer, the web or your smart phone
- Automatic alerts keep fleet managers up to date on the latest machine notifications



- Knowledge is power make informed decisions to manage your fleet better
- Knowing your idle time and fuel consumption will help maximize your machine efficiency
- Take control of your equipment - any time, anywhere









### **SPECIFICATIONS**



#### **ENGINE**

ModelKomatsu SAA6D125E-7* TypeWater-cooled, 4-cycle AspirationTurbo-charged, after-cooled, cooled EGR Number of cylinders6
Bore
Stroke
Piston displacement
GovernorAll-speed, electronic
Horsepower:
SAE J1995Gross 224 kW <b>301 HP</b>
ISO 9249 / SAE J1349Net 223 kW 299 HP
Rated rpm 2000 rpm
Fan drive method for radiator coolingHydraulic
Fuel systemDirect injection
Lubrication system:
MethodGear pump, force-lubrication
Filter Full-flow type
Air cleaner
dust evacuator, plus dust indicator

\*EPA Tier 4 Final emissions certified



### **TRANSMISSION**

Torque converter......3-elements, 1-stage, 2-phase Transmission......Automatic full-powershift, countershaft type

Travel sp	eed Forward*	Reverse*
1st	7.3 km/h <b>4.5 mph</b>	7.5 km/h <b>4.7 mph</b>
2nd	12.7 km/h <b>7.9 mph</b> (13.3 km/h <b>8.3 mph</b> )	13.1 km/h <b>8.1 mph</b> (13.8 km/h <b>8.6 mph</b> )
3rd	22.2 km/h <b>13.8 mph</b> (23.8 km/h <b>14.8 mph</b> )	22.9 km/h <b>14.2 mph</b> (24.5 km/h <b>15.2 mph</b> )
4th	35.4 km/h <b>22.0 mph</b> (38.5 km/h <b>24.0 mph</b> )	36.6 km/h <b>22.7 mph</b> (39.0 km/h <b>24.2 mph</b> )
*P-mode	Measured with 26.5-R25 tires	(): Lock-up clutch ON



### **AXLES AND FINAL DRIVES**

Drive system	Four-wheel drive
Front	Fixed, semi-floating
Rear	Center-pin support, semi-floating,
	26° total oscillation
Reduction gear	Spiral bevel gear
Differential gear	Conventional type
Final reduction gear	Planetary gear, single reduction



#### **BRAKES**

Service brakes	Hydraulically actuated,
	wet disc brakes actuate on four wheels
Parking brake	Wet disc brake
Emergency brake	Parking brake is commonly used



### **STEERING SYSTEM**

Type Articulated type, fully-hyd	raulic power steering
Steering angle 35° each direction (	40° to max end stop)
Minimum turning radius at	
the center of outside tire	6630 mm <b>21' 9"</b>



### HYDRAULIC SYSTEM

Steering system: Hydraulic pump
Type
Bore x stroke
Loader control: Hydraulic pump
Type
Lift cylinder
Boom Raise, hold, lower, and float Bucket Tilt-back, hold, and dump
Hydraulic cycle time (rated load in bucket) Raise





### **SERVICE REFILL CAPACITIES**

Cooling system	. 81 Itr	21.4 U.S. gal
Fuel tank (	380 Itr	100.4 U.S. gal
Engine	38 ltr	10.0 U.S. gal
Hydraulic system	173 Itr	45.7 U.S. gal
Axle front	59 Itr	15.6 U.S. gal
Axle rear	59 Itr	15.6 U.S. gal
Torque converter and transmission	. 65 ltr	17.2 U.S. gal
DEF tank	.36 ltr	9.5 U.S. gal




### **BUCKET SELECTION GUIDE**





## DIMENSIONS



Tread	Standard Loade	r 2300 mm	7'7"
	Yard Loader	2314 mm	7'7"
Width over standard tires	Standard Loade	r3010 mm	10'
Width over 775/65R29 tires	Yard Loader	3150 mm	10'4"
A Wheelbase		3450 mm	11'4"
B Hinge pin height, max. height		4505 mm	14'9"
C Hinge pin height, carry position		585 mm	1'11'
D Ground clearance		525 mm	1'8"
E Hitch height		1210 mm	4'
F Overall height, top of the stack		3220 mm	11'7"
G Overall height, ROPS cab		3575 mm	11'9"
F Overall height, top of air brake cooling	Yard Loader	3600 mm	11'10"

Measured with 26.5-R25(L3) Tires, ROPS/FOPS cab

		Standard Boom	
	General Purpose Bucket	Loose Material Bucket	Loose Material Bucket
	Pin On	Pin On	Pin On
	Bolt-on Cutting Edge	Bolt-on Cutting Edge	Bolt-on Cutting Edge
Bucket capacity: heaped	4.6 m <sup>3</sup>	5.0 m³	5.5 m <sup>3</sup>
	<b>6.0 vd</b> <sup>3</sup>	<b>6.5 vd³</b>	<b>7.2 yd<sup>3</sup></b>
struck	4.0 m <sup>3</sup> <b>5.2 yd<sup>3</sup></b>	4.3 m <sup>3</sup> <b>5.6 yd<sup>3</sup></b>	5.0 m <sup>3</sup> <b>6.5 yd<sup>3</sup></b>
Bucket width *with bucket side guard	3170 mm	3170 mm	3190 mm
	<b>10'5</b> "	<b>10'5"</b>	<b>10'5"</b>
Bucket weight	2387 kg	2458 kg	2608
	<b>5262 lb</b>	<b>5419 lb</b>	<b>5750 lb</b>
H Dumping clearance, max. height and 45° dump angle*	3165 mm	3095 mm	3025 mm
	<b>10'5</b> "	<b>10'2"</b>	<b>9'11"</b>
I Reach at max. height and 45° dump angle*	1440 mm	1530 mm	1600 mm
	<b>4'9"</b>	<b>5'0"</b>	<b>5' 3"</b>
J Reach at 2130 mm 7' clearance	2165 mm	2205 mm	2240 mm
and 45° dump angle*	<b>7'1"</b>	<b>7'3"</b>	<b>7'4"</b>
K Reach with arm horizontal and bucket level*	3080 mm	3180 mm	3274 mm
	<b>10'1"</b>	<b>10'2"</b>	<b>10'9"</b>
L Operating height (fully raised)	6280 mm	6375 mm	6375 mm
	<b>20'7"</b>	<b>20'11"</b>	<b>20'11"</b>
M Overall length (bucket on ground)	9375 mm	9475 mm	9575 mm
	<b>30'9"</b>	<b>31'1"</b>	<b>31'5"</b>
Loader clearance circle (bucket at carry, outside corner of bucket)	15420 mm	15475 mm	15525 mm
	<b>50'7"</b>	<b>50'9"</b>	<b>50'11"</b>
Digging depth: 0°	90 mm	90 mm	90 mm
	<b>3.5"</b>	<b>3.5"</b>	<b>3.5"</b>
10°	365 mm	385 mm	400 mm
	<b>1'2"</b>	<b>1'3"</b>	<b>1'4"</b>
Static tipping load: straight	20205 kg**	20100 kg**	21295 kg
	<b>44,544 lb**</b>	<b>44,313 lb**</b>	<b>46,947 lb</b>
40° full turn	17540 kg**	17435 kg**	18345 kg
	<b>38,669 lb**</b>	<b>38,437 lb**</b>	<b>40,444 lb</b>
Breakout force	206 kN	193 kN	182 kN
	21000 kgf	19700 kgf	18530 kgf
	<b>46,297 lb</b>	<b>43,431 lb</b>	<b>40,915 lb</b>
Operating weight	25960 kg**	26030 kg**	27810 kg
	<b>57,232 lb**</b>	<b>57,386 lb**</b>	<b>61,311 lb</b>
Equipped with 775/65R29 tires	No	No	Yes

<sup>\*</sup>At the end of tooth or B.O.C.E. (Bolt on cutting edge)

All dimensions, weights, and performance values based on ISO 7131, ISO 14397-1 and ISO 7546 standards.

Static tipping load and operating weight shown include lubricant, coolant, full fuel tank, ROPS cab, and operator. Machine stability and operating weight affected by counterweight, tire size, and other attachments.

<sup>\*\*</sup>Effective from S/N A48081, 100438



### **WEIGHT AND DIMENSION CHANGES**

Tires or attachments	Operating weight		Tipping load straight		Tipping load full turn		Width over tires		Ground clearance		Change in vertical dimensions	
	kg	lb	kg	lb	kg	lb	mm	in	mm	in	mm	in
26.5-25-20PR(L-4)	+340	+750	+239	+527	+211	+465	3010	119	525	21	0	0
Remove additional counterweight	-378	-833	-924	-2037	-769	-1695						



### STANDARD EQUIPMENT

- 2-spool valve for boom and bucket control
- Alternator, 90 A
- Auto shift transmission with mode select system
- Automatic Digging System
- Automatic hydraulic-driven fan with automatic reverse rotation
- Back-up alarm
- Batteries, 140 Ah/12V (2), 930 CCA
- Battery disconnect with lockout
- Boom Kick-out, in-cab adjustable
- Bucket Positioner, in-cab adjustable, 3 positions
- Color rear view camera and monitor
- Counterweight, standard and additional
- Electronically Controlled Suspension System (ECSS)
- Engine, Komatsu SAA6D125E-7 diesel
- Engine shut-off system, electric
- EPC fingertip controls with F-N-R switch, two levers
- Equipment Management Monitoring System (EMMS)
  - Lights (central warning, brake oil pressure, engine oil pressure, parking brake, cooling fan reverse, KDPF restriction, seat belt caution, Komtrax message)

- Gauges (Engine water temperature, ecology, fuel level, DEF level, hydraulic oil temperature, speedometer/tachometer)
- Front fenders
- Fuel pre-filter with water separator
- Horn, electric
- Integrated Load Meter (2 lever only)
- Komatsu SmartLoader Logic
- Komatsu Auto Idle Shutdown
- KOMTRAX® Level 5
- Lift cylinders and bucket cylinder
- Lights
- Back-up light, LED
- Stop and tail light, LED
- Turn signal lamps, 2 front and 2 rear with hazard switch
- Working lights, halogen, 2 front cab mount
- Working lights, halogen, 2 front fender mount
- Working lights, halogen, 2 rear grill mount
- Loader linkage with standard lift arm
- Lock-up torque converter
- Parking brake, electric Radiator, wider core
- Radiator mask, swing out
- Rear full fenders
- Rear view mirrors, outside (2) inside (2)
- Rims for 26.5-25 tires

- ROPS/FOPS Cab Level 2
  - 2 x DC12V electrical outlets
  - Ashtray
  - Auto air conditioner
  - Cigarette lighter, 24V
  - Color LCD/TFT multi-monitor
  - Cup holder
  - Floor mat
  - Operator seat, reclining, air suspension type, heated
  - Radio, AM/FM with AUX input jack
  - Rear defroster, electric
  - Seatbelt, 2-point retractable, 76mm 3" width
  - Space for Lunch box
  - Steering wheel, tilt and telescopic
  - Sun visor, front window
  - Windshield washer and wiper, front with intermittent
  - Windshield washer and wiper, rear
- Service brakes, wet disc type
- Starting motor, 7.5 kW
- Transmission, 4 forward and 4 reverse
- Vandalism protection kit, padlocks for battery box (2)



### **OPTIONAL EQUIPMENT**

- Advanced Joystick Steering System (AJSS)
- Auto Lube System
- Auxiliary steering (SAE)
- Block heater and oil pan heater
- Cutting edge (bolt-on type)
- Engine pre-cleaner with extension
- Limited slip differential (F&R)
- Load Meter Printer (2 lever only)
- Monolever loader control with transmission F-N-R switch (not compatible with AJSS)
- Various tire options, radial and bias
- Various bucket options

© 2021 Komatsu Ltd. or one of its subsidiaries. All rights reserved.

Printed in USA

AD04(POD)

02/25 (EV-8)



All comparisons and claims of improved performance made herein are made with respect to the prior Komatsu model unless otherwise specifically stated.

#### www.komatsuamerica.com

Product designs, specifications and/or data in this document are provided for informational purposes only and are not warranties of any kind. Product designs and/or specifications may be changed at any time without notice. The only warranties that apply to sales of products and services are Komatsu's standard written warranties, which will be furnished upon request. Komatsu and other trademarks and service marks used herein are the property of Komatsu Ltd. or its subsidiaries, or the respective owners or licensees.